

WWW.TRGEAR.COM 701 E Plano Pkwy, Suite 500 PLANO, TX 75074 800-561-7612

THE TICK

COLT 1911

MOUNTING INSTRUCTIONS

QUICK INSTALL

OF THE SLIDE STOP PIN (SSP) LIFT THE TICK OVER THE TIE USING THUMB OR FINGERNAIL AND SLIDE THE TICK ON

WARNING: SHOULD YOU TRANSFER YOUR TICK FROM ONE COLT TO ANOTHER, YOU MUST REPEAT THE INSTALLATION INSTRUCTIONS BELOW

QUICK REMOVAL
LIFT THE TICK OVER THE TIP OF THE SSP USING THUMB OR FINGERNAIL AND SLIDE THE TICK OFF

FIRST INSTALLATION WITH ONE TIME ADJUSTMENT NOTE: IT IS IMPORTANT THAT YOU FOLLOW THESE INSTRUCTIONS TO ENSURE THE CORRECT FIT FOR YOUR TICK LIGHT AND LASER MOUNT. (FAILURE TO FOLLOW THESE INSTRUCTIONS MAY RESULT IN THE TICK "DROOPING" WHEN THE WEAPON IS FIRED)

STEP 1 - FOLLOW YOUR WEAPON USER MANUAL TO STRIF AND REMOVE THE SSP; REPLACE THE SSP WITH THE ELONGATED SSP PROVIDED IN THE KIT.



STEP 2 - BACK OUT THE TEFLON SCREW ON THE TICK USING A SMALL, FLAT BLADED, SCREWDRIVER, OR SIMILAR INSTRUMENT/TOOL



STEP 3 - SLIDE THE TICK DOWN THE FRAME AND OVER THE ELONGATED SSP. THE SSP MUST PROTRUDE THROUGH THE HOLE IN THE ARM OF THE TICK (TO ENSURE A SNUG FIT, RESS DOWN ON THE ARM OF THE TICK)

STEP 4 - Firmly grasp the frame of the weapon and the TICK with one hand. Run in the Teflon screw until it just makes contact with the trigger guard. (Do NOT over tighten!)



THE TICK IS NOW INSTALLED AND READY FOR YOUR LIGHTS OR LASERS.

WARRANTY: THE TICK COMES WITH A ONE-YEAR WARRANTY COVERING ANY DEFECT IN MANUFACTURING OR MATERIALS